
GARVEY[®] JIFFI CUTTER

The Jiffi Cutter is an industry favorite for box cutting. Has one blade depth, with easy to change blades, it is easy to use and light weight

• To open Jiffi Cutter, grasp metal sleeve between thumb and forefinger with dimpled end down. The "Jiffi Cutter" imprint should

face away from your palm. Push down on a hard surface. To close, grasp the sleeve in the same manner, with blade facing away from your and push down on a hard surface.



Close unit after every use

• To change the blade, start with the blade in the closed position. Dimple will now be showing in the blade carrier. With the dimple (high spot) facing you, grasp the outside sleeve with one hand, the

carrier with the other and pull apart the two pieces. Please take extra caution to protect yourself from the blade as the blades are sharp and you can get cut.

PULL PULL

• Place the carrier edge down on a hard surface. Grasp the blade firmly by the folded, exposed non-

cutting edge. Pull and rotate up.Insert new blade.To re-insert the carrier,



JIFFI CUTTER

As with any box cutting or sharp cutting tool

- Please use extreme caution -
- **Caution:** Knives are intended for cutting only and should be handled with care. Bending blade can cause it to break, possibly resulting in bodily injury. Blades are sharp. Handle and dispose of with care.
- Do not use when on medication, intoxicated or drowsy
- Keep away from minors
- When not in use make sure the cover is over the blade and then lock in a safe place
- Always wear appropriate clothing, including gloves and safety glasses
- Be careful not to cut towards any part of your body
- The user acknowledges that the cutter is inherently dangerous if not properly used and assumes all risk of all damages and losses resulting from improper use

reverse as you took apart.

Contact your Garvey Sales Representative

Garvey Products

5428 Duff Drive • West Chester, OH 45246 800.543.1908 Website: www.garveyproducts.com Email: garveycares@garveyproducts.com